



Installing your sign - French Cleat - Interior (No Hardware)

Tools Needed:

- 1) Level
- 2) Drill
- 3) Drill bits
- 4) Wall anchors appropriate for the weight/size of your sign (not provided)

Prep Work:

- 1) Determine where the studs are in your wall
- 2) Line up your wall cleat so that it can be anchored into the wall studs with the appropriate anchoring hardware (not provided)

Instructions

- 1) Place the cleat on the wall, making sure its holes line up with the studs in your wall
- 2) Make sure the cleat is level, **if you have a template**, make sure the bottom of the cleat is on the line marked on the template.
- 3) With a pencil, mark the wall through the holes on the cleat. Mark the furthest left, right and middle hole. We typically recommend one hole every 16 inches.
- 4) Remove the cleat and drill a pilot hole through your marks.
- 5) Drill each of the holes again but with the bit size recommended for your wall anchors.
- 6) Insert anchors into each hole.
- 7) Place the provided cleat on the wall and screw it into place, into each anchor.
- 8) Now carefully hook the cleat that is on the back of your sign into the cleat that is on the wall.